

Technical Datasheet

TR 500

Description	Tile fixation for inspection door
Reference	TR 500
Retention Force	5 kg
Quantity	4 pcs / Blister
Illustration	

Mounting instructions :

1. Attach the magnetic catches to each corner of the access opening.
2. The magnetic catches are fixed in the adhesive bed between the tiles and the wall.
3. If access opening is in a corner, the magnetic catches on the adjacent wall must be bent by 90°.
4. Assemble the access cover out of the tiles, with a central tile to hold the cover together. Line up the 4 counter plates with the magnetic catches previously installed and glue onto the access cover. Now the cover can be fitted and the joints can be grouted.